



75814
Bouton Touch



75815
Sachet cable Y



75835
Sachet bouton de
cartouche M30 (lot de
2)



90185
SACHET GRILLE
DL400/DL300 (X1)



90478
Sachet grille complet
6l/mn



90739
SCH.BOUTON
MITIGEUR THERMOS
X1



90743
1DOUCHETTE A MAIN
CHROMEE 1JET



90744
FLEXIBLE GRIS MAT FF
G1/2 (X1)



90887
Cartouche seule
mitigeur thermostatique



90904
5 Garnitures



90941
Sachet pile CRP2



91030
KIT POMME
PRESTOTEM2



91031
KIT CAPOT BAS



91032
KIT CAPOT HAUT



91033
SCHT JOINT 5 CASSET
PRESTOTEM2



91034
SCHT FLEXIBLE ALIM
PRESTOTEM2



91035
SCHT ROBINET ARRET



91036
Sachet Barre de
douchette



91045
Sachet electrovanne



91141
KIT PLATINE
PRESTOTEM2 TOUCH
(1EV)+MTH-POMME



91142
KIT PLATINE
PRESTOTEM2 TOUCH
(1EV)+MTH-DOUCH



91197
Sachet pile complet